

QUICK START GUIDE

+ Application Instructions

BEFORE YOU START



RECOMMENDED FABRICS

100% Cotton, 100% Polyester, Poly/Cotton Blends



SUPPLIES

- HTV material
- Electronic vinyl cutter (Roland, Graphtec, Cricut®, Silhouette Cameo®, other)
- Heat press or iron
- Weeding tool
- Sturdy, flat surface
- Blank T-shirt/garment



PREPARATION

1. If pre-washing garment, wash without fabric softener.

2. Recommended: To verify cut settings, perform a small test cut prior to cutting full designs.

3. Recommended: To verify application settings and to test on sensitive fabrics, perform a test print prior to applying full job.



CUT

Have your design ready to go in your cutting software. Place your HTV material shiny side down, load it in your vinyl cutter, and start cutting. Don't forget to mirror your design horizontally before cutting! If you don't, it will appear backwards when transferred onto your garment.



WEED

Remove any excess and unwanted material away from the design using a weeding tool.



PREP

- Set heat press to recommended time, temperature, & pressure settings
- Place garment on lower platen of heat press
- Preheat garment for 2-4 seconds to remove any wrinkles and moisture



APPLY

- Place & position cut design onto garment with the shiny liner side up, sticky-side down
- Close & lock heat press for recommended application time. Open heat press and slowly peel away carrier. Peel hot, warm, or cold per material application instructions.



CUTTER + APPLICATION GUIDELINES

CAD-CUT® METALLIC

CUTTER	BLADE	FORCE	OFFSET	SPEED
Roland DG GS-24	45°	60-90g	.25	30cm/s
Graphtec	45°	8-10	0	30cm/s

CUTTER	SETTINGS	PRESSURE/FORCE	SPEED	BLADE TYPE
Cricut®	Iron-On	-	-	Standard
Silhouette®	-	6	8	3
Brother	-	5	4	3

APPLICATION-HEAT PRESS

Time: 8–10 seconds

Temp: 285°F/140°C

Pressure: Medium

Peel: Cold

APPLICATION-HOME IRON

1. Set iron dial to Linen
2. Place on flat, hard surface
3. Cover design with cover sheet or other multi-purpose paper
4. Press down on iron with medium/firm pressure
5. Press each section of design for 25-30 seconds. Flip item over & iron on the underside of the design for an additional 25-30 seconds
6. If areas of design lift after application, replace cover sheet & re-press for 10 seconds
7. Peel carrier cold

POST CARE



CARE

Machine wash cold, inside-out, using mild detergent on delicate setting. Do not use bleach. Dry at a normal dryer setting on household machines. Do not dry clean.



STORAGE

Store in a cool and dry area around 65-70°F with 50% relative humidity. Keep away from direct heat, sunlight, and humidity. Recommended shelf life is one year.