

Goof Proof®

For application on cotton, polyester or cotton/poly blends.

1. PREPARE YOUR MACHINE

Allow for warm up time.

Temperature: **360° - 370°**

Time: **3-5 Seconds**

Pressure: **Med/Firm 6-8**



PREHEAT BOTTOM PAD

Before applying, lock the top platen down for 60 seconds.
This helps the ink to flow properly during application.

Note:

These recommended time, temperature and pressure settings are for Stahls' Hotronix® heat seal machines. Settings on other heat presses may vary based on their inconsistencies. For heat presses other than Hotronix® use a temperature setting 10° hotter.

Goof Proof® Tip:

This product can also be applied at 340 degrees, for 10 seconds, peeling warm.

2. PREPRODUCTION

- Please check transfers carefully before applying. We provide an extra transfer for testing to your quality standards.
- Cut the transfer into 4 pieces and apply on test material until desired results are achieved. If you are unable to get desired results, please call us before starting job.



3. PREHEAT GARMENT

- Place garment on platen.
- Press for 3-5 seconds or until there is no more steam to remove wrinkles and moisture.
- Check to be sure there are no obstructions such as buttons, pockets or seams. If there are, raise the print area only with Print Perfect pad or mouse pad.



4. POSITION & PRESS

- Place the transfer face down on the garment.
- Close the machine.
- Press for 3-5 seconds.



5. PEEL HOT

- Open the machine.
- Peel off the transfer paper quickly in a smooth, even motion.

