## **DESCRIPTION**

Our Woven Patches offer best of both worlds! Thread & Flexibility while maintaining the traditional look. We offer you our interlaced weaving process with intricate designs without the need for fabric. Available in up to 63 colors. We offer Woven Patches with backing options of low melt heat seal & pressure sensitive making the possibilities for applications endless! Finished with a stitched border.

## **PATCH SIZE LIMITS**

**Area** - Min 1.5" X 1.5" Max 7.48" X 7.48"

## **TEXT AND ELEMENTS**

Minimum elements and text size: .2 mm wide x 2 mm height.

## COLOR

A minimum of 2 colors must be used and maximum of 6 colors per patch (excluding the border).

## **BACKING**

Woven Patches are available with Pressure Sensitive or Heat Applied backing.

## **BORDER**

Woven Patches are available with stitched border. The edge must be 6mm (+/- 1mm) space with stitched border.

## **BORDER SIZE**

4mm (+/- 1mm)

## **ELECTRONIC PROOF**

Digital simulated sample -3 business days. Edits are allowed - charges may apply

## **WASHING INFORMATION**

Woven Patches will withstand up to 50 domestic washing machine cycles.

## **SHELF LIFE**

To maximize the shelf life of this product please keep at room temperature. Do not expose it to temperatures above 485 degrees.

#### **DISCLAIMER**

The alignment of the logo and out edge may vary by +/- 2mm. Patches are at risk of irregularities due to the nature of the production.





## **HEAT APPLY WITH A PROFESSIONAL HEAT PRESS**

#### HOTRONIX® 360 IQ® HAT PRESS

Time: 15-20 seconds

Temp: 280°F Upper / 320°F Lower

Pressure: Medium

Cover Sheet: 1/8" Foam Pad

## **HEATED UPPER PLATEN**

Time: 15-20 seconds

**Temp:** 360° F

Pressure: Medium-Firm

Cover Sheet: FlexStyle® Silicone Pad or 1/8" Foam Pad

 Pre-heat bottom platen for 60 seconds and fabric for 20 seconds.

## **HEATED UPPER & LOWER PLATEN**

Time: 15-20 seconds

Temp: 280°F Upper / 320°F Lower

Pressure: Medium-Firm

Cover Sheet: FlexStyle® Silicone Pad or 1/8" Foam Pad

• For best results, Stahls' recommends applying with a heated lower platen.

#### **CAP PRESS**

Time: 15-20 seconds

**Temp:** 360°F **Pressure:** Medium

Cover Sheet: FlexStyle® Silicone Pad or 1/8" Foam Pad

Instructions: Pre-heat the lower platen for 60 seconds. Load cap and pre-heat 20 seconds. Cover with Flex Pad and press.

r da dila press.

### **FABRIC COMPATIBILITY**

## **Heat Applied:**

- 100% Cotton
- · 100% Polyester
- Cotton/Poly Blends

## **Pressure Sensitive:**

· Smooth surfaces on hard goods

## PRESSURE SENSITIVE APPLICATION

# PRESSURE-SENSITIVE (STICKER) APPLICATION

- Make sure the application area is thoroughly cleaned. Rubbing alcohol can be used.
- Remove paper backing and press firmly on the desired location.
- For best results, please allow at least 24 hours cure time.

## **FOR USE ON**

Smooth, hard surfaces. Not recommended for surfaces that may contain an oil finish such as silicone or any type of outdoor goods.

